

## Van 'n Bike Frame Holder Assembly Instructions



Insert the bolt supplied through the hole in the fixing bracket.



Then fix this in the hole with thread in the middle of the upper horizontal tube of the Van 'n Bike. Tighten with spanner size 13 and put the black cap on the bolt head.

*Only for the Van 'n Bike model up to and including 2020: First remove the strap bracket in the middle of the upper horizontal tube. The 2021 model no longer has this bracket.*

When tightening you can choose to position the Frame Hold higher or lower by turning the fixing bracket half a turn.



OR



You can change the position of the clamp with “grippers” by sliding it forwards or backwards over the Frame Holder tube. Use Allen key no. 6 for loosening and tightening.

The clamp with “grippers” can also be turned upwards.



You can also take the clamp off the tube and turn it around with the star button facing inwards.



You can change the position of the clamp in different ways depending on the cycle carrier you put on the Van ’n Bike.

When in the correct position you can place the clamp with “grippers” around the bracket of your cycle carrier and tighten with the star button.



Finally, tighten the Frame Holder star button in the fixing bracket.

If no cycle carrier is assembled, the Frame Holder can also be tightened with the star button so it is fixed tight while driving.